

Mattenfilter





- → Jetlifter™ driven, no air stone
- Heater and bulkhead are installed behind the Poret® foam to hide them and prevent fish from going down the drain
- Overflow can be conveniently installed behind the sheet without the need for a strainer

Water flow

P
O
Bulkhead
(optional)

e
t
R
Airline

